

Iron on instructions:

- **Step 1: Set your hand iron at temperature 190 degree Celsius for pre-heating 5 minutes. DO NOT USE STEAM DURING APPLICATION!**
- **Step 2: Place your applique or embroidered patch in the desired position and place a pressing cloth (such as a handkerchief, sheet or pillowcase fabric) over top.**
- **Step 3: Press the iron firmly for 25 seconds with a slow circular motion and as much constant pressure as possible**
- **Step 4: Turn the garment inside-out and repeat steps 2 & 3.**
- **Step 5: Allow the applique or embroidered patch to cool down completely.**
- **Care attention: Laundry washing in cold water under 40 degree Celsius with mild detergent**